FLEXIGLAS FIXED PANEL

Assembly Instructions

COBURN SLIDING SYSTEMS

Section View



LH = Opening Height
TH = Glass Door Height
FGH = Fixed Glass Height

1 Door + 1 Fixed Panel



1 Door + 2 Fixed Panel



TB = Glass Door Width
LW = Passage Width
FGB = Fixed Glass Width
FW = Fixed Glass Side Rail
FB = Fixed Glass bottom Rail

i 1 sided Fixed Panel



i 2 sided Fixed Panel



FLEXIGLAS FIXED PANEL

Assembly Instructions

1



Wall mounting



Ceiling mounting



FLEXIGLAS FIXED PANEL

Assembly Instructions

2

Fixing Bottom Rail



Fixing Side Rail



FLEXIGLAS FIXED PANEL

Assembly Instructions

3



1. Stick the spacers in the rails
2. Insert the glass in the top rail
3. Then push it in the bottom rail
4. Then slide it in the side rail

FLEXIGLAS FIXED PANEL

Assembly Instructions

4

Secure the glass by fixing rubber seals



1. Fix the rubber seals in the bottom rail
2. Cut the extra bits
3. Fix the rubber seals in the top rail
4. Fix the rubber seals in the side rail
5. Fix the end cap

FLEXIGLAS FIXED PANEL

Assembly Instructions

5







1. Cut the cover for the fixed panel top rail to passage width
2. Clip the cover on the top rail

FLEXIGLAS FIXED PANEL

Assembly Instructions

6



Fix track end cap

7

In case of 2 sided fixed panel



1. Cut the cover for running track
2. Click the metal arc in the cover
3. Insert the cover inside the running track
   then position as per the pictures and fix it.

COBURN SLIDING SYSTEMS
Integrating Style & Function

For further information on our products and services:
Tel: +44 (0)20 8545 6680 sales@coburn.co.uk www.coburn.co.uk
Coburn Sliding Systems Ltd
Unit-1, Cardinal West, Cardinal Way, Godmanchester
Cambridgeshire, PE29 2XN United Kingdom