


SLYDE 50

Door Specification

Max Door Weight: 50kg,

Door Thickness: 14mm - 45mm,

Max Door Height: 2700mm



FITTING MANUAL

2 & 3 DOOR SYSTEM

$$DWi - \text{Door Width (2 Door)} = \frac{OW - 2F}{2} + 10$$

$$DWi - \text{Door Width (3 Door)} = \frac{OW - 2F}{3} + 15$$

S = Door Thickness, between 14mm and 45mm

OW - Opening Width


H - Inside Height of Wardrobe

h1 = Door Height, h1 = H - 12


F - Thickness of Side Panel

S1 = Gap between the doors




2 DOOR



3 DOOR



W1 = OW - 2F - 20



Equipment Needed



SCREWDRIVER

A Phillips head screwdriver.



RULER

Size: 300mm.

System Components



TRACK (2 DOOR / 3 DOOR)

Article Number: 866

Quantity: 4 Pieces

* Available in 2 meters (866-20), and 3 meters (866-30).



FITTINGS PACK (2 DOOR / 3 DOOR)

Article Number: 86701/ 86702

Rollers: 8 Pieces / 12 Pieces

Soft Closing Dampers : 4 Pieces

Track End Cap: 8 Pieces

Fixing Screws: 32 Pieces / 48 Pieces

Allen Key: 1 Piece

Figure 1.





Figure 2.



1. Place the dampers 60mm into the top track*. Ensure the dampers are facing in the correct direction as guided in **Figure 1**.
2. Once the dampers have been placed. Place the track end Caps into the track, as guided in **Figure 2**.

NOTE:

*The bottom tracks do not require dampers



1. Place the track assembly into the slots on the bottom panel. Repeat this step for the top panel, as guided in [Figure 3](#).
2. Tighten the Track end stops to fix, as guided in [Figure 4](#).



Figure 5.







Figure 6.

Distance from the edge of the Door: 135mm

Height: 49mm
Width: 60mm
Depth: 12mm

1. Ensure the slots are symmetrical when cut.
2. Cut out the slots required using the dimensions guided in [Figure 6](#).



1. Fix the rollers to the door using the screws supplied, as guided in [Figures 7 and 8](#).
2. Ensure the rollers are horizontal during the installation process. Lock the rollers by pushing down the wheel and sliding the clip inwards, as guided in [Figure 9](#).



Figure 9.



Figure 10.




Figure 11.




Figure 12.

1. Place the inner door/s on the centre of the bottom track. Ensure the door/s are not tilted more than 20° during installation, as guided in [Figure 9](#).
2. Softly push the inner door/s onto the bottom track as guided in [Figure 10](#).
3. Unlock the roller by pushing up the wheel and sliding the clip outwards, as guided in [Figure 11](#).
4. Carefully direct the upper roller into position as guided in [Figure 12](#), then unlock the roller.
5. Repeat the previous 4 steps for the outer door.



Figure 13.



Figure 14.



Figure 15.

1. Push the door to the end of the track, as guided in [Figure 13](#). This will position the damper.
2. Locate the screw on the face of the roller and screw to regulate the door gap. Repeat this step for all of the rollers, until the perfect gap has been achieved, as guided in [Figure 7](#).
3. Using the Allen Key, fix the dampers, as guided in [Figure 7](#). Ensure both ends and all dampers have been fixed.



2 DOOR WARDROBE



3 DOOR WARDROBE

SLYDE 50



Unit 1, Cardinal West,
Cardinal Distribution Park,
Godmanchester,
Huntingdon,
Cambridgeshire, PE29 2XN

Tel: +44 (0) 20 8545 6680

www.coburn.co.uk