



STEPS

1. Fix the retainer plates onto the top of the door in the centre (**Figure 1**).
2. Insert the pulleys into both ends of the track with the wheel facing inwards, tighten to secure (**Figure 2**).
3. Locate the plastic cover around the steel wire, cut 100mm from the end of the plastic cover (**Figure 3**).
4. Make a loop at the end of the steel wire, and wrap it around the left screw of the retainer plate (**Figure 4**).
5. Working your way anti-clockwise, continue wiring the system, working your way through the grooves of the pulleys (**Figure 5a**), and the second retainer plate making a loop around both screws (**Figure 5b**).
6. Once you have reached the starting point, close the doors adjust the cable length.
7. Remove the plastic cover, and make a loop at the end of the steel wire. Attach the wire retainer and wrap around the right screw on the retainer plate (**Figure 5c**).
8. The system is ready to use.